



Warpage and Strain of a record are resolved!



Vacuum style stabilizer will adsorb warpage and strain of a record to the pure magnesium disc, which will improve unwanted resonance and low resolution, and play the best sound quality.

Product Specification (Contents)

Supportive Record Player

Check the length of spindle after the turntable sheet of the record

player is removed.

Straight Section

Over 10mm

Length

Spindle

- Magnesium Disc
- Outside diameter: Φ305mm Thickness: 7mm Weight: 660g Material: Pure Magnesium, Synthetic rubber
- Suction Adaptor
- Outside diameter: Φ 313mm Inner perimeter: Φ 52mm Weight: 980g Material: Steel, Urethane rubber
- ●Suction Box
- Size: (W) 68mm (D) 120mm (H) 62mm Weight: 380g Material: Steel
- Power: DC9V(006P Battery) * Batteries are not included.
- Suction Collar
- Outside diameter: (upper) \$\Phi\$25mm (lower) \$\Phi\$50mm Weight: 150g
 Material: Stainless. Steel, Synthetic rubber

How to Operate



Remove the turntable mat and set the magnesium disc.



Turn on the suction box switch, and it will complete suction in 20 mins.



(If a record has a large warpage)

Put the suction adaptor on the turntable and perform the suction operation.



When adsorbed, remove the suction collar. It is ready to play a record.

DS Exports